


AIRPORT DIAGRAM

SEATTLE/BOEING FIELD/KING COUNTY INTL (BFI)
AL-384 (FAA)
SEATTLE, WASHINGTON

ATIS 127.75
BOEING TOWER 120.6 257.8
GND CON 121.9
CLNC DEL 132.4

NW-1, 30 AUG 2007 to 27 SEP 2007



RWY 13R-31L
S100, D160, ST175, DT340
RWY 13L-31R
S35, D60
Rwy 13R ldg 9120'
Rwy 13L ldg 3470'
Rwy 31L ldg 9120'
Rwy 31R ldg 3345'

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READEBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM

SEATTLE, WASHINGTON
SEATTLE/BOEING FIELD/KING COUNTY INTL (BFI)